

Welcome to the
Quickfencer 50.

Barb Arm Instructions

Quickfencer Operation



The barb arm should be carefully attached to the left side of the machine as you look at it from the front. In your setup, you will find the bolts and fixing plates. These should be screwed on as per the images shown here.



The barb arm can be moved into two positions.

Setting the barb arm at a 45° angle to the QF50 puts it into working position. Setting the arm to 180° angle to the QF50 puts it into a stowed position. The arm is held in place by the provided red key.



The bolts holding the barb arm in place should be securely tightened. The barb spiders may then be secured onto the arm at the appropriate spacing. The spool holders should be put in place and constructed as described in the pictures.

Quickfencer Operation



The spool holders should be assembled as shown and the bolts tightened. Repeat this process for all mounts.



The assembled Quickfencer should look like the picture above. You will have attached up to 5 spiders in total. To run one strand of barbed wire over your woven wire, please refer to the appropriate guide.

Thanks for using Quickfencer!

Please always exercise caution when using our machines, and refer to our safety guidelines.

www.quickfencerusa.com | Tel: 715-203-0075

